

3 Axis Joystick Keyboard

Manual

V1.0



CONTENTS

1. SUMMARY -----	3
2. SPECIFICATION -----	3
3. TECHNICAL PARAMETER -----	3
4. REAR PANEL -----	3
5. FRONT PANEL-----	4
6. EXTERNAL CONNECTION -----	4
7. OPERATION SPECIFICATION-----	4
8. KEYBOARD OPERATION -----	5
9. TROUBLESHOOTING -----	14

IMPORTANT SAFETY GUARDS

Please observe the following safety measures, when install and use such product:

1. Please read and keep this manual.
2. The installation and maintenance of such product should be operate under the operation regulations by professional.
3. Please do not install the product on the table or bracket unstably.
4. Please read carefully and understand the all information of this manual before install and use this product, and keep it as a reference.
5. Please do not let any object fall into the product.
6. Use this product according to the warning sign and the direction.
7. Please pull out the power supply, before clear such product. Do not use the liquid or spray cleaner.
8. Only use the power supply style marked on the product: DC 12V/2.0A.

1. SUMMARY

Such Keyboard is a product supporting with Intelligence Dome Camera, decoder and other terminal receivers. It connects to the receiver by EIA/RS-485 electric interface. Without the bus driver, one keyboard at most to control 32 domes or decoders, and the longest communication distance is 1.2Km. the intelligence dome camera can be controlled and setup expediently by such control keyboard, and it can also control the terminal decoder directly, achieve the control to the Pan/Tilt, lens, light, wiper and other front equipments.

2. SPECIFICATION

- 5" color LCD screen, display the front four channel images directly
- Build in four multiplexer, switch the image optionally
- 3 Axis shift gears joystick
- OSD menu function
- Integrated 16 protocols, baud rate range: 2400bps ~ 19200 bps
- RS-485 and RS-232 output, can control the many front equipments, including the intelligence dome camera, decoder, Multiplex etc.

3. TECHNIQUE PARAMETER

- The communication mode from dome camera to keyboard: Asynchronous Interface Half Duplex Serial Communication
- Baud rate: 2400bps, 4800bps, 9600bps, 19200bps
- Communication distance: at most 1200 meters
- Power supply: DC12V/2.0A
- Measure: 390×165×80 (mm)
- Weight: 2 Kg
- The amount to control the Pan/Tilt or Dome: at most 32 pcs.

4. BACK PANEL




Figure 1

- ① DC power supply input: DC12V/2.0A.
- ② RS232 output: to control the external Multiplexer
- ③ RS485 output: to control the dome camera or the Pan/Tilt.
- ④ Video input: 4 video input port , to connect four camera or other standard video signal source.

It means the current address is 001, the baud rate is 2400bps, the protocol code is P003 (the corresponding relations of the protocol code with the protocol will be listed in Table 2), the video format is PAL, the version code is V1.2 After 10 seconds, it will be displayed to keyboard operation interface, the content of input data buffer, the control mode, and the current address will be displayed at the furthest bottom of the screen. As the following picture, the input data is 0000, keyboard is under speed dome mode (detail explain refer as **CONTROL MODE** item in page 10), and the current address is 001.

DATA: 0000	DOME	ID: 001
------------	------	---------

! : Please setup the address, protocol and the baud rate of the keyboard same to the dome or Pan/Tilt, before control it, or the dome or Pan/Tilt will out of control by communication failure.

8. KEYBOARD OPERATION

8.1. SPPED DOME OPERATION

8.1.1. modify the dome camera address CAM

- press number: "1-1024"
- press key: CAM

After modify, the area of current address will display the address inputted

8.1.2. lens become wide: WIDE

8.1.3. lens become tele: TELE

8.1.4. focus become far: FAR

8.1.5. focus become near: NEAR

8.1.6. aperture become opening: OPEN

8.1.7. aperture become closing: CLOSE

8.1.8. setup the preset position: PRESET

- press number: "1-128"
- press: PRESET

8.1.9. call preset position CALL

- press number: "1-128"
- press: CALL

8.1.10. start up tracking

- press number: "1-6"
- press: SHOT

8.1.11. setup the left point of the line scanning

- press: AUTO
- press: ON

8.1.12. setup the right point of the line scanning

- press: AUTO
- press: OFF

8.1.13. running the line scanning

- press: AUTO
- press: SHOT

Explain: some protocols do not need to setup the line scanning, just run the line scanning directly. After running, if the dome or Pan/Tilt is out of control, probably the protocol adopted does not support line scanning

8.1.14. switch on the auxiliary function

- press: FUNC
- press number: “1-10” the function of different number refer the Table 1
- press ON

Table 1 (if the function is out of control, probably such protocol is not support such operation)

NUM	CONTROL OBJECT	KEYBOARD OPERATION	
		FUNC+N+ON	FUNC+N+OFF
0	Camera Power Supply/Reset	On/ Off Switchable	Renew the Initial Value of the Camera
1	Backlight Compensation	On	Off
2	Zero Lux (refer to camera function)	On	Off
3	Menu/Screen (refer to camera function)	On	Off
4	Digital Magnification	On	Off
5	reserved	reserved	reserved
6	Focus	Auto	Manual
7	Iris	Auto	Manual
8	White Balance	Auto	Manual
9		Indoor	Outdoor
10		ATW	One Push WB

8.1.15. switch off the auxiliary function


- press: FUNC
- press: “1-10” the function of different number refer the Table 1
- press: OFF

8.1.16. control of the dome / Pan/Tilt


Move the joystick until the camera reaches desired position. To reach the fastest spin of camera, move the joystick utmost from center. Twist the joystick clockwise to zoom in and counterclockwise to zoom out.

8.1.17. the operation of keyboard menu

Press MENU to enter menu press and again to exit menu. After enter the menu, move the joystick up or down to move the cursor up or down; move the joystick left or right to adjust the content of current menu. If the option of PASSWORD is ON, the screen will display: ENTER PASSWORD:[], to tip user input the 6-digit password; If the option of PASSWORD is OFF, press MENU, to enter the MAIN MENU directly: **The factory default password is 111111.** If you modify the password, please remember the new password firmly.



SYSTEM SETTING At “SYSTEM SETTING” item, move the joystick to right, display the submenu “SYSTEM SETTING”. Move the joystick up or down to choose the menu item, and move the joystick right or left to setup the parameter.



➤ **PROTOCOL** At such item, move the joystick right or left to display: P000—P001—P002—P003—P004—P005—P006—P007—P008—P009—P010—P011—P012—P013—P014—P015 16 kinds of protocols. The corresponding of the protocol code and protocol name as following:

Table 2

CODE	NAME
P000	A01
P001	B01
P002	SANTACHI
P003	PELCO-D
P004	PELCO-P
P005	PANASONIC
P006	LONGCOMITY
P007	HD600
P008	LILIN
P009	VICON
P010	MOLYNX
P011	KALATE
P012	VCL
P013	RESERVED
P014	ALEC
P015	ULTRAK

- **BAUD RATE** At such item, move the joystick right or left to choice the four baud rates: 2400bps—4800bps—9600bps—19200bps
- **PASSWORD** At such item, move the joystick right or left to display the submenu as following:

```

    PASSWORD  SETTING
  1. PASSWORD  ON
  2. CHANGE   PASSWORD
  3. RETURN

    MENU 1.1.3
  
```

PASSWORD SETTING

- **PASSWORD ON/OFF** At menu item “CHANGE PASSWORD”, move the joystick right, to switch the ON/OFF of PASSWORD. If switch to ON, the user should input the 6-digit password to enter the menu next time.
- **CHANGE PASSWORD** At menu item “CHANGE PASSWORD”, move the joystick right, to display the submenu as following:

```

    CHANGE  PASSWORD
  1. NEW PASSWORD  -----
  2. CONFIRM      -----
  3. RETURN

    MENU 1.1.3.2
  
```

CHANGE PASSWORD

- **NEW PASSWORD** input the 6-digit password
- **CONFIRM** confirm the 6-digit password at such item, press OPEN to confirm the password after input. If the input 6-digit password same to the NEW PASSWORD, to display “PASSWORD CHANGED!”, or to display “INVALID PASSWORD!” for 3 seconds.
- **RETURN** move the joystick at such item, return to the menu (PASSWORD SETTING)
- **RETURN** move the joystick at such item, return to the menu (SYSTEM SETTING)
- **RETURN** move the joystick at such item, return to the menu (MAIN MENU)

CAMERA SETTUP At the main menu item “CAMERA SETTUP”, move the joystick right to display the submenu “CAMERA SETTUP”. Move the joystick up or down to choice the menu item and move the joystick right or left to setup the parameter.

CAMERA	SETUP
1. BACKLIGHT	ON
2. ICR SHOT	AUTO
3. IRIS	AUTO
4. D-ZOOM	ON
5. FOCUS	AUTO
6. WB SET	AUTO
7. COLOR OF CAM	B/W
8. MENU OF CAM	ON
9. RETURN	

MENU 1.2

- BACK LIGHT ON move the joystick at such item right or left to switch the back light ON/OFF.
- ICR SHOT AUTO move the joystick at such item right or left to switch the ICR SHOT ON/OFF.
- IRIS AUTO move the joystick at such item right or left to switch the IRIS AUTO/MANUAL.
- D-ZOOM ON move the joystick at such item right or left to switch the Digital ZOOM ON/OFF.
- FOCUS AUTO move the joystick at such item right or left to switch the FOCUS AUTO/MANUAL.
- WB SET AUTO move the joystick at such item right or left to switch the WHITE BALANCE SET among AUTO—MANUAL—OUTDOOR—INDOOR—ATW—ONEPUSH.
- COLOR OF CAM move the joystick at such item right or left to switch the camera image BW/COLOR.
- MENU OF CAM switch the menu or screen ON/OFF.
- RETURN move the joystick at such item right or left to return MAIN MENU

PROGRAM At the main menu item “PROGRAM”, move the joystick right to display the submenu “PROGRAM”. Move the joystick up or down to choice the menu item, and move the joystick right or left to setup the parameter.

PROGRAM
1. AUTO PAN START POS
2. AUTO PAN END POS
3. RUN AUTO PAN NORMAL
4. SET PATROL 01
5. RUN PATROL 01
6. RECORD PATTERN
7. RUN PATTERN
8. RETURN

MENU 1.3

- AUTO PAN START POS move the joystick at such item right or left to set the current position of Pan/Tilt or dome as the start point of the line scanning.
- AUTO PAN END POS move the joystick at such item right or left to set the current position of Pan/Tilt or dome as the end point of the line scanning.
- RUN AUTO PAN NORMAL move the joystick at such item right or left to run the line scanning from the start point to the end point.
- SET PATROL move the joystick at such item right or left to change the tracking number among 01-06. To

enter/ exit menu	press FUNC & <input type="checkbox"/> together (for short FUNC+ <input type="checkbox"/>)
move the menu cursor up	press FUNC & <input type="checkbox"/> /∧ together (for short FUNC+ <input type="checkbox"/> /∧)
move the menu cursor down	press FUNC & <input type="checkbox"/> /∨ together (for short FUNC+ <input type="checkbox"/> /∨)
enter the submenu	SEQ
adjust the content of current menu	TAPE
the operation of entering password	as input 1----- input number 1, and press CAM as input 2----- input number 2, and press CAM as input 3----- input number 3, and press CAM as input 4----- input number 4, and press CAM

8.2.9.2 the operation of menu

press “FUNC+”, display to input the purview password, the image is as following:

PASSWORD: [_]

Input the password: 1111, to enter the main menu:

MAIN MENU

1. SYSTEM SET
2. CAMERA SET
3. SCREEN SET
4. EVENT LIST
5. RESET DEFAULT

The system will exit the menu and return to the image before, after no operation for 3 mins.

SYSTEM SET select the item “SYSTEM SET” in main menu, and press “SEQ”, to display the submenu “SYSTEM SET”. Use FUNC+/∧) (FUNC+ /∨) to move and choice the menu item, and use (TAPE) to setup the parameter.

SYSTEM SET

TIME: 2006/03/04 16:43:16

FORMAT: ASIA [YYYY/MM/DD]

LIVE TIME DISP: TOP

BORDER DISP: GRAY

BACK COLOR: BLUE

BUZZER: OFF

ALARM TIME: 020 SEC

FREEZE TIME: 010 SEC

PASSWORD: 1111

TV FORMAT: PAL

PROTOCOL: PTC1 BAUD:9600(BPS) Do not modify this item , please!

DEVICE ID: 01(HEX)

QUTPUTFORMAT:CVBS

- TIME: system date, YYYY/MM/DD system time, HH/MM/SS.
- FORMAT: [ASIA; U.S.; EURO].
- LIVE TIME DISP: the position of live time displaying [TOP; TOP_LEFT; TOP_RIGHT; NON]
- BORDER DISP: border color [GRAY , WHITE, BLACK , OFF].
- BACK COLOR: background color [BLUE, BLACK].
- VFILTER: vision filter [ON: gentleness, OFF: clear].
- BUZZER: buzzer alert[ON, OFF].
- ALARM TIME: the holding time for alarm output。 [003—255] seconds.
- FREEZE TIME: [000—255] seconds, 000 second is mean freeze for unlimited time.
- PASSWORD: manager password [1111—4444], can setup any four-digit among 1—4.
- FORMAT: video format [PAL, NTSC], PAL is the default.
- PROTOCOL: [PTC1,PTC2,PTC3,PTC4].
- BUAD: baud rate [1200,2400,4800,9600,19200]Bps.

CAMERA SET At main menu, choice the item “CAMERA SET”, and press “SEQ”, to display the submenu “CAMERA SET”. Use (FUNC+/∧)(FUNC+/∨)to move and choice the menu item, and use (TAPE) to setup the parameter.

CAMERA MENU

CAM1
 PICTURE DISPLAY: YES
 TITLE DISPLAY: YES
 CAMERA TITLE: CAM1
 AUTO TIME: 02 SEC
 MIRROR: OFF
 PICTURE QUALITY []
 SENSOR SWITCH: ON
 SENSOR LEVEL: LOW
 DETECT TIME: 00:00 – 23:59
 MOTION SWITCH: OFF
 MOTION SET: []
 DETECT TIME: 00:00 – 23:59
 ALARM OUT
 LOSS NO SENSOR:YES MOTION:YES

- CAM: the serial number of the camera image [1—4].
- PICTURE DISPLAY: [YES , NO] .
- TITLE DISPLAY: the switcher of the camera name [YES: display, NO: disappear].
- CAMERA TITLE: edit the camera name, can use any 10 letters, digits or symbol.
- AUTO TIME: time of auto jumping [0—99] seconds.
- PICTURE QUALITY : [refer to “ setup the picture quality”].
- SENSOR SWITCH: [ON , OFF].

- SENSOR LEVEL: the effective sensor level [HIGH: for high level, LOW: for low level].
- DETECT TIME: the detect time of sensor alarm.
- MOTION SWITCH: motion alarm switcher [ON, OFF].
- MOTION SET : the setup of motion alarm [refer to 详见“the setup of motion alarm”].
- DETECT TIME: the detect time of motion alarm.
- ALARM OUT: (non)
- LOSS: the alarm output of the camera signal losing [YES , NO]. (non)
- SENSOR: the alarm output of the sensor [YES , NO] (non)
- MOTION: the alarm output of the motion [YES , NO]. (non)

SCREEN SET(don't need to adjust such item)

SCREEN SET	
OSD HORIZONTAL SET	: 03
OSD VERTICAL SET	: 01
PICTURE HORIZONTAL SET	: 07
PICTURE VERTICAL SET	: 03
PICTURE SCALE SET	: 05
(DEFAULT)	

EVENT SET(don't need to adjust such item)

EVENT LOG				
NO	CAM	DATE	TIME	EVENT
001	::	2006-3-1	14:07:01	P_ON
002	--	-----	-----	-----
003	--	-----	-----	-----
004	--	-----	-----	-----
005	--	-----	-----	-----
006	--	-----	-----	-----
007	--	-----	-----	-----
008	--	-----	-----	-----
009	--	-----	-----	-----
010	--	-----	-----	-----
PREVIOUS		NEXT	ERASE	

- NO: the recorder number of the alarm event, 001—100, amount 100.
- CAM: the camera image number of the alarm event.
- DATE: the date of the alarm event.
- TIME: the time of the alarm event.
- EVENT: the reason of the alarm event.[P_ON, boot-strap alarm; LOSS, camera signal losing alarm; MOTION, motion alarm; SENSOR, sensor alarm]
- PREVIOUS: previous page. Ten recorders one page, amount 10 pages. Press “SEQ” to turn over the page.

- NEXT: next page. Ten recorders one page, amount 10 pages. Press “SEQ” to turn over the page.
- ERASE: erase all the alarm recorders, and record from 001 newly.

RESET DEFAULT press “SEQ” to confirm the YES to resume the setup left factory. And press “SEQ” to confirm the NO to cancel it.

	CONFIRM	RESET
YES		NO

9. TROUBLESHOOTING

Problem	REASONS PROBABLY	Possible Solution
No Video	No power supply	1. Check the connection of power line 2. If the power supply is DC12V 3. Check the video connection
Can not control the appoint dome or Pan/Tilt	1. Incorrect protocol 2. Incorrect baud rate 3. Incorrect address	1. The protocol is same between keyboard and dome or Pan/Tilt? 2. The baud rate is same between keyboard and dome or Pan/Tilt?